

# XAREC<sup>®</sup> N WA 7030-02

High Heat Crystalline Polymer Blend – 30% Glass Filled Polymer  
for Automotive and Electronics Applications

Properties <sup>1</sup>	Test Method	Value	
<b>Physical</b>			
Density, g/cm <sup>3</sup>	ISO 1183	1.32	
Glass Content, %		30	
Water Absorption at 24 hrs. 50%RH, %	ISO 62	0.20	
Mold Shrinkage, flow direction, 2 mm, %	IDEMITSU <sup>2</sup>	0.2 - 0.5	
Mold Shrinkage, cross flow direction, 2 mm, %	IDEMITSU <sup>2</sup>	0.4 - 0.7	
<b>Mechanical</b>			
Tensile Strength at Break, MPa	ISO 527	175	
Tensile Modulus, MPa	ISO 527	10,000	
Tensile Elongation at Break, %	ISO 527	2.6	
Flexural Strength, MPa	ISO 178	250	
Flexural Modulus, MPa	ISO 178	9,100	
Izod Impact	Notched at 23°C, kJ/m <sup>2</sup>	11	
	Unnotched at 23°C, kJ/m <sup>2</sup>	57	
Charpy Impact	Notched at 23°C, kJ/m <sup>2</sup>	11	
	Unnotched at 23°C, kJ/m <sup>2</sup>	68	
<b>Thermal</b>			
DTUL at 1.80 MPa, °C	ISO 75 A	245	
DTUL at 0.45 MPa, °C	ISO 75 B	260	
Coefficient of Linear Thermal Expansion			
Flow direction, -30 – 30°C, mm/mm/°C	TMA	24 x 10 <sup>-6</sup>	
Cross flow direction, -30 - 30°C, mm/mm/°C	TMA	49 x 10 <sup>-6</sup>	
<b>Electrical</b>			
Comparative Tracking Index, PLC level	IEC 60112, Solution A	2	
Dielectric Constant	IEC 60250	3.2	
Volume Resistivity, Ohm-cm	IEC 60093	6.7 x 10 <sup>15</sup>	
Dielectric Strength, kV/mm	ASTM D 149	18	
Dissipation Factor	IEC 60250	0.069	
Hot Wire Ignition (HWI), PLC level	UL 746A		
		@ 1.5 mm	4
		@ 3.0 mm	4
High Ampere Arc Resistance (HAI), PLC level	UL 746A		
		@ 1.5 mm	0
		@ 3.0 mm	0
Arc Resistance, PLC level	ASTM D495	5	
<b>Flammability</b>			
Flammability, Rating	UL 94	HB	
<b>Processing</b>			
Melt Temperature, °C		280 – 310	
Mold Temperature, °C		50 – 80	
Pre-drying		80°C x1-3hrs with desiccant dryer <sup>3</sup>	

Data in this Catalogue shows sample figures measured under certain specific conditions. **Usage of products in this Catalogue does not warrant the successful results of applications of the product for specific usage.** Flammability rating in this Catalogue is not intended to reflect hazards presented by this or any other material under actual fire conditions. See "Handling Considerations" on next pages.

<sup>1</sup> All test samples molded with a 80 °C tool temperature.

<sup>2</sup> Test conducted on 80 x 80 x 2mm injection molded specimen

<sup>3</sup> XAREC<sup>®</sup> NWA grade has hygroscopic raw materials in its formula. Thus, pellet pre-drying is highly recommended under the suggested condition. Dryer temperature above 80°C shall be avoided. Careful consideration of drying times and temperatures will help avoid polymer color changing by over drying.

## Product Information

### Safety and Handling Consideration

Material Safety Data (MSD) sheets for XAREC<sup>®</sup> Crystalline Polymers are available from Idemitsu Kosan Co., Ltd. MSD sheets are provided to help customers satisfy their own handling, safety and disposal needs, and those that may be required by locally applicable health and safety regulations such as OSHA (USA), MAK (Germany) or WHMIS (Canada). MSD sheets are upgraded regularly, therefore, please request and review the most current MSD sheet before handling or using any product. The following comments are general and apply only to XAREC<sup>®</sup> Crystalline Polymers as supplied. Various additives and processing aids used in fabrication and other materials used in finishing steps have their own safe use profile and must be investigated separately.

### Hazards and Handling Precautions

This resin contains glass fibers as a reinforcing component. XAREC<sup>®</sup> Crystalline Polymers have a very low degree of toxicity and under normal conditions of use should pose no unusual problems from ingestion, eye or skin contact. However, caution is advised when handling, storing, using or disposing of these resins and good housekeeping and controlling of dusts are necessary for safe handling of product. Workers should be protected from the possibility of contact with molten resin during fabrication. Handling and fabrication of plastic resins can result in the generation of vapors and dusts, including small particles of glass fibers. Dusts resulting from sawing, filing and sanding of plastic parts in post-molding operations may cause irritation to eyes and upper respiratory tract. In dusty atmospheres, use an approved dust respirator. Granules or beads may present a slipping hazard. Slight itching and irritation may result from skin contact. Repeated exposure to particles generated by grinding glass fiber-reinforced materials may result in implantation of particles in the skin. Good general ventilation of the polymer processing area is recommended. In addition, to accelerate cooling of large polymer masses, purge patties should be quenched in water. If quenching is not possible, purge patties should be removed from the general working area to a well-ventilated area to cool.

Processing may release fumes which may include polymer fragments and other decomposition products. Fumes can be irritating. At temperatures exceeding melt temperature, polymer fragments can occur. Good general ventilation should be sufficient for most conditions. Local exhaust ventilation may be necessary for some operations. Use safety glasses. If there is a potential for exposure to particles which could cause mechanical injury to the eye, wear chemical goggles. If vapor exposure causes eye discomfort, use a full-face respirator. No other precautions other than clean body-covering clothing should be needed for handling XAREC<sup>®</sup> Crystalline Polymers. Use gloves with insulation for thermal protection, when needed.

### Combustibility

XAREC<sup>®</sup> Crystalline Polymers will burn, and once ignited, may burn rapidly under the right conditions of heat and oxygen supply. Do not permit dust to accumulate. Dust layers can be ignited by spontaneous combustion or other ignition sources. When suspended in air, dust can pose an explosion hazard. Dense black smoke is produced when product burns. Toxic fumes are released in fire situations. Fire fighters should wear positive-pressure, self-contained breathing apparatus and full protective equipment. Water or water fog are the preferred extinguishing media. Foam, alcohol resistant foam, carbon dioxide, or dry chemicals may also be used. Soak thoroughly with water to cool and prevent re-ignition.

### Disposal

DO NOT DUMP INTO ANY SEWERS, ON THE GROUND, OR INTO ANY BODY OF WATER. For unused or uncontaminated material, the preferred options include sending to a licensed recycler, re-claimer, incinerator or other thermal destruction device. For used or contaminated material, the disposal options remain the same, although additional evaluation is required (see, for example, in the USA 40 CFR, Part 261, "Identification and Listing of Hazardous Waste"). All disposal methods must be in compliance with Federal, State/Provincial and local laws and regulations.

As a service to its customers, Idemitsu can provide lists of companies which recycle, reprocess, or manage chemicals or plastics, and companies that manage used drums. Contact the nearest Idemitsu sales office for further details.

### Environment

Generally speaking, in the environment lost pellets are not a problem except under unusual circumstances – when they enter the marine environment. They are inert and benign in terms of their physical environmental impact, but if ingested by waterfowl or aquatic life, they may mechanically cause adverse effects. Spills should be minimized and they should be cleaned up when they happen. Plastics should not be discarded into the ocean or any other body of water.

## Product Information

### Product Stewardship

Idemitsu Kosan has a fundamental concern for all who make, distribute and use its products, and for the environment in which we live. This concern is the basis of our Product Stewardship philosophy by which we assess the health and environmental information on our products and then take appropriate steps to protect employee and public health and the environment. Our Product Stewardship program rests with every individual involved with Idemitsu products from the initial concept and research to the manufacture, sale, distribution, and disposal of each product.

### Customer Notice

Idemitsu encourages its customers and potential users of Idemitsu products to review their applications for such products from the standpoint of human health and environmental quality. To help ensure that Idemitsu products are not used in ways for which they are not intended or tested, Idemitsu personnel will assist customers in dealing with ecological and product safety considerations. Your Idemitsu sales representative can arrange the proper contacts. Idemitsu literature, including Material Safety Data sheets, should be consulted prior to the use of Idemitsu products. These are available from the nearest Idemitsu sales office. For further information, contact your convenient sales office listed below.

Asia	Idemitsu Kosan	+81-3-3213-9552	(Tokyo)
	Idemitsu Chemicals (Hong Kong)	+852-2802-3626	(Hong Kong)
		+86-21-5465-2255	(Shanghai)
	Idemitsu Chemicals Taiwan	+886-2-2777-3291	(Taipei)
U.S.A and Canada	Idemitsu Chemicals U.S.A.	+1-248-355-9590	(Detroit)
Europe	Idemitsu Chemicals Europe	+49-211-17734-0	(Düsseldorf)

### Medical Applications Policy for Engineering Plastic

Idemitsu will not knowingly sell or sample any products into any commercial or developmental application which is intended for:

- a. Internal body fluids or internal body tissues.
- b. Use in cardiac prosthetic devices regardless of the length of time involved (cardiac prosthetic devices include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems and ventricular bypass assisted devices);
- c. Use as a critical component in medical devices that support or sustain human life; or
- d. Use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction.
- e. Use in package directly contact with medicine or in instrument or container directly contact with fluid injected in human body.

In addition, for Idemitsu Engineering Plastics products, new business opportunities require a business assessment prior to sale or sampling Idemitsu products.

Authorized distributors and resellers will adhere to the Engineering Plastics Business medical policy.

The Engineering Plastics business does not endorse or claim suitability of their products for specific medical applications. It is the responsibility of medical device manufacturer or pharmaceutical manufacturer to determine that the Idemitsu product is safe, lawful and technically suitable for the intended use. **IDEMITSU MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CONCERNING THE SUITABILITY OF ANY IDEMITSU PRODUCT FOR USE IN MEDICAL APPLICATIONS**

**This policy applies to all Engineering Plastics products including the following resins:**

**XAREC® Crystalline Polymer**

**NOTICE:** The information and data contained herein do not constitute sales specifications. The product properties may be changed without notice. No liability, warranty or guarantee of product performance is created by this document. It is the Buyer's responsibility to determine whether Idemitsu products are appropriate for Buyer's use and to ensure that Buyer's workplace and disposal practices are in compliance with applicable laws and regulations. No freedom from any patents or other industrial or intellectual property rights is granted or implied. (May 2011)



Idemitsu Kosan Co.,Ltd.